

End drive units (驱动单元)


FlexMod®




End drive units (驱动单元)

FlexMod®


CXBEB 0A85HL Drive unit (驱动单元)
Transmission on left-hand side (传动装置在左侧)



CXBEB 0A85HR Drive unit (驱动单元)
Transmission on right-hand side (传动装置在右侧)



CXBEB 0A85HLP Drive unit (驱动单元)
Direct drive (直接单元)
left-hand side (左出轴)



CXBEB 0A85HRP Drive unit (驱动单元)
Direct drive (直接单元)
right-hand side (右出轴)

